## Application Note

## Detection of HMT SET 7/9 with the Transcreener<sup>®</sup> EPIGEN Methyltransferase Assay

This Application note will serve as a guide for using the Transcreener<sup>®</sup> EPIGEN Methyltransferase assay to detect the initial velocity enzyme activity of HMT SET 7/9 with an assay window suitable for inhibitor screening and dose response measurements. It should be used as an adjunct to the Transcreener Methyltransferase EPIGEN Assay.

#### Meera Kumar

## Histone Methyltransferase SET 7/9

SET7/9 catalyzes the transfer of methyl groups from S-adenosyl-L-methionine (SAM) to the amino function of L-lysine residues (monomethylation), espesially of lysine-4, of histone H3<sup>2</sup>. SET7/9 is essential for functions in the regulation and methylation of multiple non-histone regulatory factors including p53, p65, pRB,TAF10, SIRT1, DNMT1, the androgen receptor (AR), the farnesoid X receptor (FXR) and estrogen receptor a (ER). SET7/9 action as a coactivator for AR and its promotion of androgen-dependent cell proliferation suggests it as a potential target for prostate cancer therapy. Human recombinant SET7/9 (residues 2-366; Genbank Accession # NM\_030648) expressed as an N-terminal GST tag protein in E.coli was obtained from Reaction Biology Corp (Malvern, PA).

## Transcreener<sup>®</sup> EPIGEN Methyltransferase Assay

The Transcreener<sup>®</sup> EPIGEN Methyltransferase Assay is a universal biochemical HTS assay for enzymes that produce S-adenosylhomocysteine (SAH), including all enzymes within the histone (HMTs) and DNA (DNMTs) methyltransferase families. It combines the extensively validated Transcreener AMP<sup>2</sup>/GMP<sup>2</sup> Assay, which relies on fluorescent immunodetection of AMP, with coupling enzymes that convert SAH to AMP. Enzyme activity is signaled by a decrease in fluorescence polarization as the bound tracer is displaced from the AMP<sup>2</sup>/GMP<sup>2</sup> Antibody. The assay uses a simple mix-and-read format with two liquid addition steps. Methyltransferase (MT) enzyme reactions are first quenched with Stop Buffer and then the SAH Detection Mixture containing coupling enzymes, AMP<sup>2</sup>/GMP<sup>2</sup> antibody, and tracer is added. The assay provides excellent signal at low substrate conversion, with an assay window greater than 100 millipolarization units (mP) and Z<sup>2</sup>  $\geq$  0.7 under normal reaction conditions.




Figure 1. Transcreener Epigen methyltransferase assay principle: SAH produced in a methyltransferase reaction is converted to AMP in two sequential enzymatic steps. AMP is detected using a competitive fluorescence polarization immunoassay.

# **N**BellBrook

### **Summary of protocol**

Step 1) Determine the optimal AMP<sup>2</sup>/GMP<sup>2</sup> antibody concentration for the SET7/9 enzyme reaction.

Step 2) Perform a SET7/9 titration to determine the amount required to produce a good assay window.

Step 3) Run dose response curves.

## **Materials and Methods**

Instrument: Microplate Reader capable of measuring Fluorescence Polarization.

Microplates: Corning<sup>®</sup> 384 Well Low Volume Black Round Bottom PS NBS<sup>™</sup> Microplate (Product #3676).

Note: Non binding or Low binding black plates are necessary for a good assay window.

Reagent	Catalog #	
Transcreener® EPIGEN MT Assay	3017-1K	
SET7/9 (Reaction Biology)	HMT-11-133	
H3 peptide (1-25) (Anaspec)	61703	

HMT Enzyme Buffer: 50 mM Tris-HCl (pH 8.5), 0.1 M NaCl, 4 mM DTT, 5 mM MgCl, and 0.01% Triton X 100.

## Step 1) Determine the optimal AMP<sup>2</sup>/GMP<sup>2</sup> antibody concentration for the SET7/9 enzyme reaction.

Note: The optimal antibody concentration is primarily dependent on the SAM (2  $\mu$ M) and the peptide (10  $\mu$ M) concentration and to a lesser degree on other enzyme specific components such as metals and salts.

1) Titrate the AMP<sup>2</sup>/GMP<sup>2</sup> Antibody using a two fold dilution in a volume of 10  $\mu$ L in the HMT Enzyme Buffer containing 2  $\mu$ M SAM and 10  $\mu$ M H3 peptide.

2)Add 10  $\mu$ L of Detection Mix comprising AMP<sup>2</sup>/GMP<sup>2</sup> Tracer, Cofactor, Detection buffer, Coupling enzyme 1 and Coupling enzyme 2. The final concentrations of the components in 20  $\mu$ L reactions were 4 nM tracer, 0.125X cofactor, 0.125X detection buffer, 2  $\mu$ g/mL coupling enzyme 1 and 1  $\mu$ g/mL coupling enzyme 2.

3) Mix the plate on a plate shaker, cover with a plate seal, and incubate at RT for an hour.

 The plates were read at EXC 630 nm and EMS 670 nm to measure fluorescence polarization.

5)Plot polarization vs. log [Antibody] and determine the concentration that produces 85% of the maximal polarization change - the EC85; 3  $\mu$ g/mL in this case. In general for Transcreener assays, using the EC85 antibody concentration will allow robust detection of enzyme initial velocity (less than 20% conversion of substrate to product).




Figure 2. AMP<sup>2</sup>/GMP<sup>2</sup> antibody titration in the presence of 2  $\mu$ M SAM and 10  $\mu$ M H3 (1-25) peptide. An optimal concentration of 5  $\mu$ g/mL was determined based on this titration.

## Step 2) Perform a SET7/9 titration to determine the optimal enzyme concentration to use.

1)The final reaction volume is 15  $\mu$ L; reactions are initiated by adding 7.5  $\mu$ L of substrate to 7.5  $\mu$ L of titrated enzyme. Titrate SET7/9 using two-fold dilutions by adding 7.5  $\mu$ L aliquots to wells containing 7.5  $\mu$ L enzyme buffer starting at 70 ng/ $\mu$ L and ending at 0 ng/ $\mu$ L (the maximum enzyme concentration will be 35 ng/ $\mu$ L after addition of substrate. We suggest running duplicates, with separate controls lacking the H3 peptide and SAM.

2) Initiate the reaction by adding 7.5  $\mu$ L of substrate - Mix for final concentrations of 2  $\mu$ M SAM and 10  $\mu$ M H3 (1-25) peptide in the 15  $\mu$ L reactions per the instructions in the Transcreener EPIGEN MT Assay Technical Manual. Prepare other controls by adding just SAM or H3 peptide to the titrated enzyme reactions.

3) Incubate the enzyme reaction for two hours at 30°C.

4) Meanwhile prepare a 2  $\mu$ M SAM/SAH standard curve with 10  $\mu$ M H3 peptide in the buffer at different percent conversions. Add 15  $\mu$ L of the standards to the same plate and let them incubate at 30°C along with the enzyme reaction.

#### Note:For detailed instructions on how to run a standard curve please refer to the EPIGEN Methyltransferase technical manual.

5) At the end of two hours, add 2.5  $\mu$ L of Stop Buffer A to all the wells followed by 2.5  $\mu$ L of detection mix. The detection mix comprises of AMP<sup>2</sup>/GMP<sup>2</sup> tracer, AMP<sup>2</sup>/GMP<sup>2</sup> antibody, cofactor, detection buffer, coupling enzyme 1 and coupling enzyme 2. The final concentrations of the components in 20  $\mu$ L reactions were 4 nM tracer, 5  $\mu$ g/mL of AMP<sup>2</sup> antibody, 0.125X cofactor, 0.125X detection buffer, 2  $\mu$ g/mL coupling enzyme 1 and 1  $\mu$ g/mL coupling enzyme 2.

6) Mix the plate well and after 90 min of incubation read the plate in an instrument that measures fluorescent polarization at 633 nm EXC and 670 nm EMS.




Figure 3. SET8 enzyme titration in the presence of 2  $\mu$ M SAM and 10  $\mu$ M H3 (1-25) peptide . A concentration (EC<sub>sol</sub>) of 2.5 ng/ $\mu$ L was determined optimal based on this titration.




Figure 4. Linear relationship between Set7/9 concentration and SAH formation. The polarization values were converted into SAH (product formed) using a standard curve set up under similar conditions.

#### Step 3) Run dose response curve with sinefungin.

1) Titrate sinefungin using two- fold dilution by adding 7.5  $\mu$ L aliquots to wells containing 7.5  $\mu$ L enzyme buffer starting at 5000  $\mu$ M and ending at 0 ng/ $\mu$ L (the maximum inhibitor concentration will be 2500  $\mu$ M after addition of enzyme and substrate. We suggest running duplicates, with separate controls lacking the H3 peptide and SAM.

2) Add 5  $\mu$ L of 9 ng/ $\mu$ L of SET7/9 at EC<sub>80</sub> concentration, such that the final concentration of enzyme in the 15  $\mu$ L reaction is at 3 ng/ $\mu$ L.

3) To one row of wells add 2.5  $\mu$ L of substrate for final concentrations of 2  $\mu$ M SAM and 10  $\mu$ M peptide. Separate controls lacking SAM and H3 peptide are recommended. Incubate the plate at 30°C for two hours.

4) Add 2.5  $\mu$ L of Stop Buffer A followed by 2.5  $\mu$ L of detection mix.

5) Mix the plate well, incubate for an hour and read the plate in an instrument that measures fluorescent polarization at 633 nm EXC and 670 nm EMS.




Figure 4. Sinefungin dose response curve. The polarization values were converted into product formed using a standard curve. The  $IC_{50}$  value was determined to be 1.5  $\mu$ M.

#### Conclusions

This application note demonstrates a streamlined approach to develop a Transcreener EPIGEN Methyl transferase Assay for SET7/9. These steps can be followed to easily adapt the Transcreener EPIGEN Assay for doing high throughput screening with SET7/9.

## References & Notes

 Klink TA, Staeben M, Twesten K, Kopp AL, Kumar M, Schall Dunn R, Pinchard CA, Kleman-Leyer KM, Klumpp M, Lowery RG: Development and Validation of a Generic Fluorescent Methyltransferase Activity Assay Based on the Transcreener AMP/GMP Assay. J Biomol Screen 2012 Jan;17(1):59-70.

 Jonathan R Wilson, Chun Jing, Philip A Walker, Stephen R Martin, Steven A Howell, G Michael Blackburn, Steven J Gamblin and Bing Xiao: Crystal structure and Functional Analysis of the Histone Methyltransferase Assay. Cell 2002 Oct; 111: 105-115.

## Additional Information

#### Ordering Information

Please visit www.bellbrooklabs.com or contact BellBrook Labs for pricing for the Transcreener<sup>®</sup> Assays. Custom quotes are available for bulk orders.

Phone Orders: 608.443.2400 866.3137881

Fax Orders: 608.441.2967

Email Orders: info@bellbrooklabs.com

#### Related Products

Transcreener® ADP <sup>2</sup> FP Assay	3010-1K	
Transcreener® ADP <sup>2</sup> TR-FRET Red Assay	3011-1K	
Transcreener® ADP <sup>2</sup> FI Assay	3013-1K	
Transcreener® AMP/GMP Assay	3006-1K	
Transcreener® UDP Assay	<u>3</u> 007-1K	
Transcreener® GDP FP Assay	3009-1K	
Transcreener® GDP FI Assay	3014-1K	
Transcreener <sup>®</sup> EPIGEN Methyltransferase		
Assay	3017-1K	
Transcreener® AMP <sup>2</sup> /GMP <sup>2</sup> Assay	3015-1K	

#### Technical Information

For technical information, please contact:

#### Meera Kumar, Applications Scientist

Tel: 608.443.2400 Toll-Free: 866.313.7881 Email: meera.kumar@bellbrooklabs.com



Toll-Free: 866.313.7881 www.bellbrooklabs.com

Transcreener® HTS Assay Platform is a patented technology of BellBrook Labs.

Transcreener® is a registered trademark of BellBrook Labs.

AlexaFluor® is a registered trademark of Molecular Probes, Inc (Invitrogen).

The Transcreener® product line is the subject of U.S. Patent No. 7,332,278, 7,355,010 and 7,378,505 issued. U.S. Patent Application Nos. 11/353,500, 11/958,515 and 11/958,965, U.S. Divisional Application 12/029,932, and foreign equivalents licensed to BellBrook Labs.